



**3**

**1**

Turn the anti-jump pin to the left then remove it

**2**

Drill holes centered in door thickness for hanger anchors using a 5/16" (8mm) bit.

**Important! Please ensure the holes for the hanger are positioned in a straight line and parallel with the face of the door.**

**4**

**5**

**5**

**Optional**

**6**

**Important! Only use the stops that came with the kit. Do not add any additional stops and DO NOT use floor stops.**

(x2)

Adjust stops and be sure to tighten well.

**7**

**Anti-rise pin installation - IMPORTANT**

Install anti-rise pin as designed and detailed in IM illustration # 7 provided with the original hardware. Failure to assemble this component as illustrated could result in a malfunction of the entire assembly.

Turn the anti-jump pin clockwise until tight.

(x2)