




INSTALLATION INSTRUCTIONS FOR N-GLS9800 NARROW HEAD RIM PANIC EXIT DEVICE

BEFORE INSTALLING DEVICE, PLEASE CHECK:



1. IF DOOR IS MOUNTED AND HINGED SECURELY.
2. SIZE OF EXIT DEVICE. FUNCTION AND DESIGN...
 - 2.1. 36"(914.4mm) DOORS, CAN BE CUT TO FIT DOORS DOWN TO 30"(762mm) WIDE.
 - 2.2. 48"(1219.2mm) DOORS, CAN BE CUT TO FIT DOORS DOWN TO 36"(914.4mm) WIDE.
 - 2.3. HAND OF DEVICE AGAINST APPLICATION.




3. INSTALL HARDWARE

- 3.1 IF USING N-GLS9800 ENTRANCE LEVER TRIM:
 - 3.1.1 DEPENDING ON PROJECTION THRU DOOR, CUT CYLINDER TAIL FOR 1/4" TO 1/2" PROJECTION
 - 3.1.2 INSTALL CYLINDER ADAPTER ON RIM CYLINDER
 - 3.1.3 INSTALL CYLINDER ON DOOR
- 3.2 THRU BOLT CHASSIS TO TRIM, INSIDE DOOR SURFACE, TOP AND BOTTOM AS SHOWN IN THE DIAGRAM BELOW.

IMPORTANT:
CYLINDER ADAPTER MUST BE
INSTALLED ON CYLINDER BEFORE
INSTALLING CYLINDER INTO DOOR




1. LOCATE AND MARK THE HORIZONTAL AND VERTICAL CENTER LINES ON THE DOOR



2. PREPARE DOOR

- 2.1 USING STRIPS OF TAPE, AFFIX THE TEMPLATES ON INSIDE OF THE DOOR, ALIGNING THE MARKED REFERENCE LINES ON THE DOOR AND THE HORIZONTAL AND VERTICAL CENTERLINES OF THE TEMPLATE.
- 2.2 IF USING OUTSIDE TRIMS, MARK ALL REFERENCE LINES ON THE OTHER SIDE OF DOOR USING THE TRIM TEMPLATES
- 2.3 MAKE PILOT HOLE MARKS ON ALL DRILL HOLES
- 2.4 DRILL ALL REQUIRED HOLES



4. FASTEN RAIL ASSEMBLY

- 4.1 IF EXIT DEVICE REQUIRES CUTTING TO SIZE:
 - 4.1.1 DETERMINE CUT OFF LENGTH "X" BY SUBTRACTING 1-3/4" FROM "Y"
 - 4.1.2 MARK CUT OFF POINT IN MOUNTING RAIL
 - 4.1.3 CUT OFF AND DEBURR
- 4.2 PRESS DOWN ARM INTO RAIL OPENING AND PUSH IN RAIL ONTO THE CHASSIS.
- 4.3 LEVEL RAIL AND FASTEN MOUNTING PLATE

