

Architectural Door Accessories

ASSA ABLOY

Pemko Floor Molding, Trim & Handyshapes

The global leader in
door opening solutions

Applies to the following products:

2131, 2120, 2604


Installation Instructions:

1. Measure length of carpet or seam to be covered.
2. Measure, mark and trim carpet bar to length using tin snips or hacksaw.
3. Place carpet bar over carpet or seam and nail in place:
 - a. Wood floor installation: secure to floor with supplied nails.
 - b. Concrete floor installation: secure to floor using rawl pugs (rawl plugs not included).



↑
**Trims
Carpet
Edge**

Tools Required:



www.pemko.com

MEMPHIS, TN USA P: 800 824-3018 F: 800 243-3656	VENTURA, CA USA P: 800 283-9988 F: 800 283-4050	VANCOUVER, BC CA P: 877 535-7888 F: 877 535-7444	TORONTO, ON CA P: 877 535-7888 F: 877 535-7444
---	---	--	--

Copyright © 2017 Pemko Manufacturing Co., an ASSA ABLOY Group company. All rights reserved.
Reproduction in whole or in part without the express written permission of Pemko Manufacturing Company is prohibited.

FM1_WEBINS
Rev 2 - 01.25.17
Page 1 of 1