

Applies to the following products:

356_V, 359

Installation Instructions:

1. Measure, mark, & trim door astragal to full length of door, leaving vinyl seal slightly longer than the metal (for best seal, vinyl should touch header at top and threshold (or floor) at bottom).
2. Secure astragal in place with supplied screws.

Tools Required:

