






911373-00

98/99

VON DUPRIN®

Rim Exit Device

Installation Instructions














**Dogging Key**  
(use to lock down pushbar)





**Customer Service**  
1-877-671-7011 [www.allegion.com/us](http://www.allegion.com/us)

© Allegion 2015  
Printed in U.S.A.  
911373-00 Rev. 11/15-g

## SCREW CHART

Subassembly	Screw		Application
<p><b>A</b></p>  <p>299 Strike    499F Strike</p>		<p>#10-24 x 3/4" (19 mm)</p> <p>#10 x 1 1/2" (38 mm) Wood screw</p>	<p>Metal frame</p> <p>Wood frame</p>
<p><b>B</b></p> 	 <p>Packaged with 990 Trims:</p>	<p>#10-24 x 1" (25 mm)</p> <p>#10-24 x 1 1/2" (38 mm)</p> <p>#10 x 1 1/4" (32 mm) Wood screw</p> <p>#10-24 x 1 3/8" (35 mm)</p> <p>#10-24 x 1 7/8" (48 mm)</p>	<p>Surface mount or Sex bolts 1 3/4" (44 mm) door</p> <p>Sex bolts, 2 1/4" (57 mm) door</p> <p>Surface mount (wood)</p> <p>1 3/4" (44 mm) door, 990 Trim</p> <p>2 1/4" (57 mm) door, 990 Trim</p>
<p><b>C</b></p> 		<p>#10-24 x 3/4" (19 mm)</p> <p>#10-24 x 1 1/8" (29 mm)</p> <p>#10 x 1 1/4" (32 mm) Wood screw</p>	<p>Surface mount or Sex bolts 1 3/4" (44 mm) door</p> <p>Sex bolts, 2 1/4" (57 mm) door</p> <p>Surface mount (wood)</p>
<p><b>D</b></p> 		<p>#10-16 x 3/8" (10 mm) Thread cutting</p>	<p>End cap</p>
<p><b>E</b></p> 		<p>#10-24 x 1" (25 mm)</p> <p>#10 x 1 1/4" (32 mm) Wood screw</p>	<p>Surface mount (metal)</p> <p>Surface mount (wood)</p>
<p><b>F</b></p> 		<p>#8-18 x 3/8" (10 mm) Thread cutting</p>	<p>Center case cover</p>


**1 Draw horizontal device and strike center lines (☉).**




\* For double doors with a mullion and strike already installed, use existing strike center line.

**2 Align strike on ☉ and mark the two slotted holes.**

ⓘ For 499F strike installation, see page 6.




ⓘ For more information on the strikes shown below, go to <http://w3securitytechnologies.com> and look for the Support area for Von Duprin installation instructions.



**3 Prepare 2 holes and install 2 screws.**

ⓘ See "Screw Chart" on previous page for screw types and sizes




<b>Metal</b>	#25	#10-24


OR

<b>Wood</b>	1/8" (3 mm) x 1" (25 mm) deep


**4 Position template against strike and on ☉ and mark door.**



**5 If necessary, prepare cutouts for cylinder and trim.**




## 6 Prepare 4 center case mounting holes.



SURFACE MOUNT		OR	SEX BOLTS or 990 TRIMS	
WOOD	METAL	WOOD	METAL	1/4" (6 mm) Device Side
	#25		METAL	13/32" (10 mm) Trim Side
WOOD	#10-24	WOOD	METAL	13/32" (10 mm) Drill Thru
	1/8" (3 mm) x 1" (25 mm) Deep		METAL	

## 7 Prepare 2 center case support holes.




METAL		OR	WOOD	
98/99 and 98/99-F		WOOD	98/99	
#25	1/8" (3 mm) x 1" (25 mm) Deep		98/99-F	
#10-24		#825 Sex bolts (2) required		

## 8 If necessary, remove NL drive screw

### NL drive screw

Factory installed on back of center case



With the NL drive screw removed, key locks and unlocks lever, knob, or thumb piece. For the trims listed below, **REMOVE** NL drive screw.


996L	696TP	990TP
996K	697TP	

With the NL drive screw installed, key retracts latch bolt. **DO NOT** remove NL drive screw for the following applications:

NL, EO, DT trims and 98/99-2 double cylinder devices (i.e. TP-2, L-2, and K-2).


*996L-BE	*E996L	*696TP-BE	*990TP-BE
*996K-BE	*E996L-BE	*697TP-BE	

\* If the trim being installed is "BE" (i.e. 996L-BE), the trim lock tumbler on the back of the device must be in the **UP** position before device is installed. This allows the trim to be unlocked at all times.




## 9 If using a cylinder with a tailpiece, prepare device and cylinder.


### 9a Install tailpiece guide.



### 9b Cut tailpiece as needed.




**10** If necessary, cut device.




**12** Mark and prepare two (2) holes.


**i** Prepare holes after lock side of device is mounted and hinge side is leveled.



**11** Attach center case to door.




**13** Install end cap bracket and end cap.




**14** Install required support screws and center case cover.

Remove protective film from pushbar




**15** Adjust strike as needed.


299/299F Strike



Shim as needed




**16** Install strike support screw.



METAL	WOOD
#25	1/8" (3 mm) x 1" (25 mm) Deep
#10-24	


**499F STRIKE INSTALLATION**

1. Prepare and install screws through two strike slots.




**i** If using a mullion, holes may be predrilled

2. Install strike hook and additional strike screws.





3. Template aligns as shown.




## OPTIONAL EQUIPMENT

### CD (Cylinder Dogging) Option







Dog




Undog

# OPTIONAL EQUIPMENT

## 99-2 (Double Cylinder) Option



For 98/99-2SI models with Classroom Security Indicator, apply supplied labels above and below cylinder to match door handing, and label on indicator.



**Manually affix the label:**

Ensure surface is clean of dirt, dust, or oils. Clean with alcohol if necessary.

Peel the label from the paper backing and apply to the surface. Minimize handling when applying and use pressure to burnish label to surface. The adhesive will require up to 8 hours to achieve the proper bond.

